


Graphics by WIRED4



World-Wide Studies
of ILC Physics and Detector


ILC Detector Simulation Using Geant4

Jeremy McCormick
SLAC LCD Simulations Group




ILC Detector Concepts


2







SiD



GLD




LDC



Z Higgs ($M_H=120$ GeV) event \rightarrow same simulator, three different detector geometries

Performance Requirements

3




To measure complex final states
of e+e- collisions at $\sqrt{s} = \sim 1$ TeV,
a detector must have

- Exceptional momentum resolution
- Excellent vertexing capabilities
- Highly granular readout in all subdetectors
- Hermiticity (especially in forward region)

Detector Design using Geant4


4



- one of the first collaborations to use Geant4 for ground-up design of a major HEP detector
- model different detector concepts and their variations, using Geant4 for prototyping and benchmarking
- detector description should not be hard-coded into the application → load and build at runtime
- “Let a thousand detectors bloom!” (or at least 2-3 dozen)

Readout Technologies


5




- trackers
 - pixel, Silicon microstrip, TPC
- sampling calorimeters
 - Electromagnetic: Silicon, scintillator, hybrid
 - Hadronic: scintillator, GEM, RPC
 - absorbers: Steel, Tungsten (others?)
- Machine Detector Interface /
Beam Delivery System (MDI-BDS)

Example Detector Topology

6




SiD (barrels only)



Simulation Framework


7



Simulator for the Linear Collider (SLIC)
Linear Collider Detector Description (LCDD)
Geometry Description Markup Language (GDML)
Linear Collider IO (LCIO)

SLIC Simulator


8



- C++ user application using Geant4 toolkit
- hub package → most of functionality implemented in subpackages
- standard data formats for ILC
 - LCIO (output): HEP data model with generic Calorimeter and Tracker hits
 - StdHep (input): physics events
 - LCDD (input): GDML-based geometry system
- command line or macro commands / interactive

LCDD Geometry System

9



LCDD

Identifiers

Sensitive Detectors

Regions

Physics Limits

Visualization

Magnetic Fields

GDML

Expressions (CLHEP)








Materials

Solids

Volumes


LCDD Geometry Examples

10





Geant4 Data Binding

11




Area	Root Element	Geant4 Class(es)
Sensitive Detectors	<sensitive_detectors>	G4VSensitiveDetector
Identifiers	<iddict>	NA (custom classes)
Regions	<regions>	G4Region, G4VUserRegionInformation
Physics Limits	<limits>	G4UserLimits
Visualization	<display>	G4VisAttributes
Magnetic Fields	<fields>	G4MagneticField
Constants	<define>	NA (CLHEP expressions)
Materials	<materials>	G4Material, G4Element
Shapes	<solids>	G4VSolid
Volumes	<structure>	G4LogicalVolume, G4VPhysicalVolume

LCDD XML Format



Sensitive Detectors and Identifiers

13




Sensitive Detectors

```
<calorimeter name="EMBarrel" hits_collection="EcalBarrHits">  
  <idspecref ref="EcalBarrHits"/>  
  <projective_cylinder ntheta="1000" nphi="2000"/>  
</calorimeter>
```

Identifiers

```
<idspec name="EcalBarrHits" length="54">  
  <idfield signed="false" label="layer" length="7" start="0" />  
  <idfield signed="false" label="system" length="6" start="7" />  
  <idfield signed="false" label="barrel" length="3" start="13" />  
  <idfield signed="false" label="theta" length="11" start="32" />  
  <idfield signed="false" label="phi" length="11" start="43" />  
</idspec>
```

Regions, Fields & Limits



Regions

```
<region name="TrackingRegion"
  store_secondaries="true"
  cut="10.0"
  lunit="mm"
  threshold="1.0"
  eunit="MeV">
  <limitsetref ref="TestLimitSet"/>
</regions>
```


Fields

```
<solenoid name="GlobalSolenoid"
  inner_field="solenoid_inner_field"
  outer_field="solenoid_outer_field"
  zmin="solenoid_zmin"
  zmax="solenoid_zmax"
  inner_radius="solenoid_rmin"
  outer_radius="solenoid_rmax"
  funit="tesla"
  lunit="mm"/>
```

Physics Limits

```
<limits>
  <limitset name="TestLimitSet">
    <limit name="step_length_max" particles="*" value="1.0" unit="mm"/>
    <limit name="track_length_max" particles="pi+, pi-, p0" value="100.0" unit="cm"/>
  </limitset>
</limits>
```


Volume Element



```
<volume name="EcalBarrelEnvelope">  
  <materialref ref="Air"/>  
  <solidref ref="EcalBarrelTube"/>  
  <sdref ref="EcalSD"/>  
  <regionref ref="EcalBarrelRegion"/>  
  <limitsetref ref="EcalBarrelLimits"/>  
  <visref ref="EcalBarrelLimits"/>  
  <phsvol>  
    <volumeref ref="EcalLayer1"/>  
    <physvolid id="1"/>  
  </physvol>  
</volume>
```

Compact Detector Description


16



- geometry format for reconstruction and analysis & event display
- core concepts
 - detectors, layers, slices, readouts
- translate Compact to other formats
 - LCDD (simulation)
 - HepRep (event display)
 - GODL (fast simulation with Ielaps)
 - Java runtime (reconstruction)
- easy to change → regenerate target formats

Compact Description Example

17




Two different layer stacks in same Ecal.

```
<detector id="2" name="EMBarrel" type="CylindricalBarrelCalorimeter"
readdout="EcalBarrHits">
  <dimensions inner_r = "150.1*cm" outer_z = "208.0*cm" />
  <layer repeat="20">
    <slice material = "Tungsten" thickness = "0.25*cm" />
    <slice material = "G10" thickness = "0.068*cm" />
    <slice material = "Silicon" thickness = "0.032*cm" sensitive = "yes" />
    <slice material = "Air" thickness = "0.025*cm" />
  </layer>
  <layer repeat="10">
    <slice material = "Tungsten" thickness = "0.50*cm" />
    <slice material = "G10" thickness = "0.068*cm" />
    <slice material = "Silicon" thickness = "0.032*cm" sensitive = "yes" />
    <slice material = "Air" thickness = "0.025*cm" />
  </layer>
</detector>
```

Detector Variants


18




cdcaug05_ecal150




sidaug05_polyhedra




sid00




hd3_1-oct-05



ld3_1-oct-05




glAug05



Geant4-generated HepReps drawn by WIRED4.


How do we work with Geant4?

19



- ILC physics list
 - LCPhys by Dennis Wright (Geant4 team)
- GDML (geometry sub-project)
 - build system, bug fixing, features
- bug finding
 - parameterized volumes (2004)
 - EM/HAD physics “anomalies” (ongoing)
- model test beam geometries (CALICE)

Links



LCSim Homepage	http://www.lcsim.org
Detector Resources	http://www.lcsim.org/detectors
SLIC	http://www.lcsim.org/software/slic
LCDD	http://www.lcsim.org/software/lcdd
GDML	http://gdml.web.cern.ch/GDML/
LCIO	http://lcio.desy.de
ILC Sim Wiki	http://confluence.slac.stanford.edu/display/ilc/
SiD	http://www-sid.slac.stanford.edu/
LDC	http://www.ilcldc.org/
GLD	http://ilcphys.kek.jp/gld/